

HOW TO SETUP MOTION RECORDING

1. At the recorder, *Right* Click > Enter **MENU** > **CAMERA** > **MOTION**
2. Check box to **ENABLE MOTION DETECTION**
3. Click **FULL SCREEN** or **CLICK & DRAG MOUSE ACROSS SCREEN**
4. Entire screen should have **RED BOXES**
5. Set **SENSITIVITY BAR** in the middle
 - a. Left is less sensitive and Right is more sensitive
6. Select **APPLY** > Select **COPY** > Check all Boxes to copy settings to all cameras
7. Select **OK** > Select **APPLY**